


[Home](#)



OS-9[®] for GraphicsClient/ GraphicsClient Plus Board Guide

Version 4.7



RadiSys.
THE POWER OF WE

www.radisys.com

Revision A • July 2006

Copyright and publication information

This manual reflects version 4.7 of Microware OS-9. Reproduction of this document, in part or whole, by any means, electrical, mechanical, magnetic, optical, chemical, manual, or otherwise is prohibited, without written permission from RadiSys Microware Communications Software Division, Inc.

Disclaimer

The information contained herein is believed to be accurate as of the date of publication. However, RadiSys Corporation will not be liable for any damages including indirect or consequential, from use of the OS-9 operating system, Microware-provided software, or reliance on the accuracy of this documentation. The information contained herein is subject to change without notice.

Reproduction notice

The software described in this document is intended to be used on a single computer system. RadiSys Corporation expressly prohibits any reproduction of the software on tape, disk, or any other medium except for backup purposes. Distribution of this software, in part or whole, to any other party or on any other system may constitute copyright infringements and misappropriation of trade secrets and confidential processes which are the property of RadiSys Corporation and/or other parties. Unauthorized distribution of software may cause damages far in excess of the value of the copies involved.

July 2006
Copyright ©2006 by RadiSys Corporation
All rights reserved.

EPC and RadiSys are registered trademarks of RadiSys Corporation. ASM, Brahma, DAI, DAQ, MultiPro, SAIB, Spirit, and ValuePro are trademarks of RadiSys Corporation.

DAVID, MAUI, OS-9, OS-9000, and SoftStax are registered trademarks of RadiSys Corporation. FasTrak, Hawk, and UpLink are trademarks of RadiSys Corporation.

† All other trademarks, registered trademarks, service marks, and trade names are the property of their respective owners.

Contents

Chapter 1: Installing and Configuring OS-9®

Requirements and Compatibility	8
Host Requirements (PC Compatible)	8
Target Hardware Requirements	8
Java Hardware Requirements	9
Target Hardware Setup.....	9
Configuring the ATA Card.....	9
Connecting the Target to the Host.....	9
Building the OS-9 ROM Image.....	11
Overview.....	11
Coreboot	11
Bootfile	11
Starting the Configuration Wizard	11
Creating a Startup File.....	15
Optional Procedures	16
Connecting the Reference Board to an Ethernet Network	16
Pinging the Target.....	17
Creating a New OS-9 Coreboot Image in Flash Memory	18
Making a Coreboot Image with an EPROM Programmer	18
Compressing the Bootfile Image	19

Chapter 2: Board-Specific Reference

Boot Options	22
Booting from FLASH	22
Booting from PCMCIA ATA Card.....	22
Booting from Ethernet.....	22
Booting over Serial Communications Port via kermit	22
Restart Booter	23
Break Booter	23
The Fastboot Enhancement.....	24
Overview.....	24
Implementation Overview	25
B_QUICKVAL	25
B_OKRAM.....	25
B_OKROM	25
B_1STINIT	25
B_NOIRQMASK.....	26
B_NOPARITY	26
Implementation Details	26
Compile-time Configuration	26
Runtime Configuration.....	27
OS-9 Vector Mappings	27

Fast Interrupt Vector (0x7)	30
GPIO Usage	30
GPIO Interrupt Polarity	31
Port Specific Utilities.....	31
pcmcia	32
pflash	34
touch_cal	36
ucbtouch	37

Appendix A:

Board-Specific Modules

Low-Level System Modules	40
High-Level System Modules.....	41
CPU Support Modules	42
System Configuration Modules.....	42
Interrupt Controller Support	42
Real Time Clock	42
Ticker.....	42
Abort Handler.....	42
Generic IO Support Modules (File Managers)	43
Pipe Descriptor.....	43
RAM Disk Support	43
Descriptors for Use with RAM	43
Serial and Console Devices.....	44
Descriptors for Use with sc1100	44
Descriptors for Use with sc16550	44
Descriptors for Use with sc110	44
PCMCIA Support for IDE Type Devices	45
Descriptors for Use with rb1003.....	45
PCMCIA Support for 3COM Ethernet Card.....	45
Descriptors for Use with spe509_pcm.....	45
Network Configuration Modules.....	45
SMC91C94 Ethernet Support	45
Descriptor for Use with sp91c94.....	45
Network Configuration Modules.....	45
UCB1200 Support Modules.....	46
Descriptors for Use with spucb1200	46
Maui Graphical Support Modules.....	46
Descriptors for Use with gx_sa1100	46
Descriptors for Use with sd_ucb1200	46
MAUI Configuration Modules.....	46
MAUI Protocol Modules	46

Appendix B: MAUI Driver Descriptions

GraphicsClient Objects	48
MAUI objects.....	48
GX_SA1100 LCD Graphic Driver Specification	48
Board Ports	48
Device Capabilities.....	49
Display Resolution	49

Coding Methods	50
Viewport Complexity	50
Memory	50
Location	50
Build the Driver	51
Build the Descriptor	51
SD_UCB1200 Sound Driver Specification	51
Device Capabilities	51
Gain Capabilities Array	52
Sample Rates	53
Number of Channels	53
Encoding and Decoding Formats	54
SPUCB1200 driver for the UCB1200 Codec	54
Capabilities	54
Descriptors	54
UCB	55
Audio	55
Touch Screen	55
GPIO	55
Telecom	56
Supporting Modules	56
MP_UCB1200 MAUI Touch screen Protocol Module	56
Overview	56
Data Format	56
Data Filter	56
Raw Mode	56
cdb.touch	57
Compile Time Options	57
Calibration Application	57
Assumptions/Dependencies	58
Command Line Options	58
Coordination with Protocol Module	58
Compiling	58

1

Installing and Configuring OS-9®

This chapter describes installing and configuring OS-9® on the ADS SA-1100 Microprocessor Reference Platform (GraphicsClient) and the ADS SA-1110 Microprocessor Reference Platform (GraphicsClient Plus).

For information about...	Go to this page...
Requirements and Compatibility	8
Target Hardware Setup	9
Connecting the Target to the Host	9
Building the OS-9 ROM Image	11
Creating a Startup File	15
Optional Procedures	16

Requirements and Compatibility



Before you begin, install the *Microware OS-9 for StrongARM* CD-ROM on your host PC.

Host Requirements (PC Compatible)

Your host PC should have the following installed:

- Windows 95/98 or Windows NT/2000
- a minimum of 64MB of free disk space (an additional 200MB of free disk space is required to run PersonalJava Solution for OS-9)
- an Ethernet network card
- a PCMCIA card reader/writer
- at least 16MB of RAM
- a terminal emulation program (such as Hyperterminal that comes with Microsoft Windows)



If you are a PersonalJava Solution for OS-9 licensee and you plan to use the Java JCC to pre-load your Java classes, you may need as much as 64MB of RAM. Refer to the document *Using JavaCodeCompact* for a complete discussion of using the JCC.


Target Hardware Requirements

Your reference board requires the following hardware:

- a GraphicsClient power supply
- an RS-232 null modem serial cable
- an LCD touch screen, serial mouse, and PS/2 keyboard

The J4 connector controls the touch panel on the GraphicsClient. OS-9 does not allow the swapping of positive (P) and negative (M) connectors, or the swapping of X and Y pairs. To ensure a proper connection, use the following connector pinouts:

Figure 1-1. J4 Connector Pinout Diagram



•

Java Hardware Requirements

Below are the requirements for run PersonalJava Solution for OS-9:

- 16MB of RAM
- 4MB of FLASH (Boot)
- LCD Display



The *Graphics Client User's Manual* (#100110-40025) and *GraphicsClient Plus User's Manual* (#100110-80011) are provided by Applied Data Systems, Inc. You can download them from www.applieddata.net.

Target Hardware Setup

Configuring the ATA Card

You can use your ATA card to validate that your reference board is operational without requiring the connection to the host machine:

To configure the ATA card, complete the following steps:

- Step 1. From a DOS prompt on the host machine, navigate to the following directory and run `os9make`:

```
MWOS\OS9000\ARMV4\PORTS\GRAPHICSCLIENT\BOOTS\SYSTEMS\PORTBOOT
```

- Step 2. On the host machine, copy the following file into the root directory to the ATA card:

```
MWOS\OS9000\ARMV4\PORTS\GRAPHICSCLIENT\BOOTS\SYSTEMS\PORTBOOT\os9kboot
```

- Step 3. Install the card in the single PCMCIA socket on the reference board.

Connecting the Target to the Host

To connect the target to the host, complete the following steps:

- Step 1. Connect an RS-232 null modem cable from the reference board to the serial port of a Windows system.
- Step 2. Connect the serial cable to the J10 connector (or the DB9 connector that connects to J10) on the reference board. The J10 connector is the SA11X0 serial port 3 (SP3).
- Step 3. Connect the other end of the serial cable to the Host PC.
- Step 4. On the Windows desktop, click on the **Start** -> **Programs** -> **Accessories** -> **Hyperterminal**.
- Step 5. Open Hyperterminal and enter a name for your Hyperterminal session.
- Step 6. Select an icon for the new Hyperterminal session. A new icon is created with the name of your session associated with it. The next time you want to establish the same session, follow the directions in Step 3 and look for the icon you created in Step 4.
- Step 7. Click **OK**


Step 8. In the **Phone Number** dialog, go to the Connect Using box, and select the communications port to be used to connect to the reference board.

The port selected is the same port that you connected to the serial cable from the reference board. Click **OK**

Step 9. In the **Port Settings** tab, enter the following settings:

- Bits per second = 19200
- Data Bits = 8
- Parity = None
- Stop bits = 1
- Flow control = XOn/XOff

Figure 1-2. Port Settings



Step 10. Click **OK**. A connection should be established. If the word connected does not appear in the lower left corner of the window, click **Call** -> **Connect** to establish a connection.

Step 11. Apply power to the board. The OS-9 bootstrap message is displayed.

Building the OS-9 ROM Image

Overview

The OS-9 ROM image is a set of files and modules that collectively make up the OS-9 operating system. The specific ROM image contents can vary from system to system depending on hardware capabilities and user requirements.

To simplify the process of loading and testing OS-9, the ROM image is generally divided into two parts—the low-level image, called `coreboot`; and the high-level image, called `bootfile`.

Coreboot

The coreboot image is generally responsible for initializing hardware devices and locating the high-level (or bootfile) image as specified by its configuration. This might be from a FLASH part, a hard disk, or Ethernet. It is also responsible for building basic structures based on the image it finds and passing control to the kernel to bring up the OS-9 system.

Bootfile

The bootfile image contains the kernel and other high-level modules (initialization module, file managers, drivers, descriptors, applications). The image is loaded into memory based on the device you select from the boot menu. The bootfile image normally brings up an OS-9 shell prompt, but can be configured to automatically start an application.

RadiSys provides a Configuration Wizard to create a coreboot image, a bootfile image, or an entire OS-9 ROM image. The wizard can also be used to modify an existing image. The Configuration Wizard is automatically installed on your host PC during the OS-9 installation process.

Starting the Configuration Wizard




Microware OS-9 for StrongARM supports ATA Flash cards.

The Configuration Wizard is the application used to build the coreboot, bootfile, or ROM image.

To start the Configuration Wizard, perform the following steps:


- Step 1. From the Windows desktop, select `Start -> RadiSys -> Microware OS-9 for <product> -> Configuration Wizard`. You should see the following opening screen:

Figure 1-3. Configuration Wizard Opening Screen



- Step 2. Select your target board from the Select a board pull-down menu.
- Step 3. Select the **Create new configuration** radio button from the Select a configuration menu and type in the name you want to give your ROM image in the supplied text box. This names your new configuration, which can later be accessed by selecting the Use existing configuration pull down menu.
- Step 4. Select the **Advanced Mode** radio button from the Choose Wizard Mode field and click **OK**. The Wizard's main window is displayed. This is the dialog from which you will proceed to build your image. An example is shown in [Figure 1-4](#).

Figure 1-4. Configuration Wizard Main Window



If you intend on using the target board across a network, proceed to the next step. If not, go directly to step nine.

- Step 5. If you want to use the target board across a network, you will need to configure the Ethernet settings within the Configuration Wizard. To do this, select **Configure** -> **Bootfile** -> **Network Configuration** from the Wizard's main menu.
- Step 6. From the Network Configuration dialog, select the **Interface Configuration** tab. From here you can select and enable the interface. For example, you can select the appropriate Ethernet card from the list of options on the left and specify whether you would like to enable IPv4 or IPv6 addressing. [Figure 1-5](#) shows an example of the Interface Configuration tab.

Figure 1-5. Interface Configuration

ETHERNET Configuration	
Cards Configured:	4
Card Types Configured:	2
Cards Enabled:	2
Cards using IPv4:	3
IPv4 from server:	2
Cards using IPv6:	3
Autoconfigure IPv6:	2



To learn more about IPv4 and IPv6 functionalities, refer to the *Using LAN* manual, included with this product CD.



Contact your system administrator if you do not know the network values for your board.

- Step 7. Once you have made your settings in the Network Configuration dialog, click **OK**.
- Step 8. Select the SoftStax® Setup tab, then select the Enable SoftStax radio button. Click **OK**. Other Network Configuration options can also be changed in this dialog according to your specific requirements and your network.
- Step 9. Select **Configure** -> **Build Image** to display the Master Builder window. If you want networking enabled, be sure the SoftStax (SPF) Support box is checked.
- Step 10. Select the **Bootfile only** radio button, then select **Build**. This will build a boot image that can be placed on the PCMCIA card.

Step 11. If it is not already powered off, turn off your board and insert the PCMCIA IDE card into the PCMCIA slot of your computer.



Inserting and removing a PCMCIA card with the power on is not supported in this release. Damage may occur to the PCMCIA card if it is inserted or removed while power is applied to the board.

Step 12. Click **Save As** to save the file `os9kboot` to the root directory of the PCMCIA IDE card.

Step 13. Remove the PCMCIA IDE card from the computer and insert the PCMCIA card into the socket on the reference board.



The GraphicsClient/GraphicsClient Plus design does not provide enough current for the Typelll PCMCIA (double height).

Step 14. Apply power to the board. The reference board will boot from the IDE PCMCIA card and you should see the “\$” prompt.



After the reference board is booted using the PCMCIA card, you can move the boot image to Flash and boot from there. To move the boot image to Flash, enter the following command at the OS-9 prompt:

```
$ pflash -i -f=/mhc1/os9kboot
```

Once the boot image has been moved to Flash, you no longer need the PCMCIA card to boot the reference board to an OS-9 prompt.

Creating a Startup File

When the Configuration Wizard is set to use a hard drive or another fixed drive, such as a PC Flash Card, as the default device, it automatically sets up the `init` module to call the `startup` file in the `sys` directory in the target (For example: `/h0/SYS/startup`, `/mhc1/SYS/startup`). However, this directory and file will not exist until you create it. To create the startup file, complete the following steps:

Step 1. If not already available, create a `sys` directory on the target machine where the `startup` file will reside (for example: `mkdir /h0/SYS`, `mkdir /dd/SYS`).

Step 2. On the host machine, navigate to the following directory:

```
MWOS/OS9000/SRC/SYS
```

You should see the following files:

- `motd`: Message of the day file
- `password`: User/password file
- `termcap`: Terminal description file
- `startup`: Startup file

Below is the example startup file as it appears in this directory:

```
-tnxnp
tmode -w=1 nopause
*
*setime </term          ;* start system clock
setime -s                ;* start system clock
link mshell csl;        * make "mshell" and "csl" stay in memory
* iniz r0 h0 d0 t1 p1 term ;* initialize devices
* load utils             ;* make some utilities stay in memory
* tsmon /term /t1 &     ;* start other terminals
list sys/motd
setenv TERM vt100
tmode -w=1 pause
mshell<>>>/term -l&
```

Because the command lines in the startup file are system-dependent, it may be necessary to modify the file to fit your system configuration. It is recommended that you modify the file before transferring it to the target machine.



Refer to the Making a Startup File section in Chapter 9 of the *Using OS-9* manual for more information on startup files.

- Step 3. Transfer all files to the newly created `sys` directory on the target machine. (You can use Kermit, or FTP in ASCII mode to transfer these files.)
- Step 4. Since the files are still in DOS format, you will be required to convert them into the OS-9 format with the `cudo` utility. The following command is an example:
- ```
cudo -cdo password
```

This will convert the `password` file from DOS to OS-9 format.



For a complete description of all the `cudo` command options, refer to the *Utilities Reference Manual* located on the Microware OS-9 CD.

## Optional Procedures

### Connecting the Reference Board to an Ethernet Network

Microware OS-9 for StrongARM supports using the onboard SMC91C94 or a 3COM Etherlink III - LAN PC Card for mwSoftStax TCP/IP connections. Also, Microware OS-9 for StrongARM provides system level support for telnet, FTP, and NFS.

To use Ethernet networking, you must create a bootfile that has the Ethernet options enabled and insert an Ethernet PCMCIA card into the reference board if you choose to use a PCMCIA Ethernet card.

Complete the following steps to connect your board to an Ethernet network:

- Step 1. From the Windows desktop, select `Start -> RadiSys -> Microware OS-9 for <product> -> Configuration Wizard`. Open the Wizard using the steps from the [Starting the Configuration Wizard](#) section.
- Step 2. From the Wizard menu, select `Configure -> Bootfile -> Network Configuration`. The Network Configuration dialog box appears.
- Step 3. Change the network settings as needed. Refer to the Configuration Wizard help for more information on the network settings.
- Step 4. Create a new Bootfile by following the directions in the [Building the OS-9 ROM Image](#) section.
- Step 5. Turn off the reference board.



Inserting and removing a PCMCIA card with the power on is not supported in this release. Damage may occur to the PCMCIA card if it is inserted or removed while power is applied to the board.

- Step 6. From here, you may proceed in one of two ways:
    1. If the on-board Ethernet interface is being used, insert PCMCIA card into the socket on the reference board.
- OR-
2. If the 3COM PC card Ethernet interface is being used, you must place the bootfile into the on-board FLASH or transfer it to the target via a `bootp` server.



- For more information on storing the bootfile in FLASH, refer to the `pflash` utility.
- For more information on booting via the `bootp` server, refer to the Booting From Ethernet section.

- Step 7. Connect the 10 Base T connector to the appropriate Ethernet interface.
- Step 8. Apply power to the board.
- Step 9. Test the Ethernet connection by pinging the reference board.

If the `ping` operation fails, you will have to evaluate the following scenarios:

- Is the board connected to a live Ethernet port?
- Is the Ethernet cable defective?
- Are the network settings for the reference board correct?

### Pinging the Target

Windows includes a `ping` command that can be used to test the Ethernet connection for the reference board.

- Step 1. Go to the DOS prompt.
- Step 2. Type `ping <IP Address>`.

The IP Address is the address you assigned to the evaluation board in either the Coreboot module or the Bootfile module. The address is typed without the <> brackets.

If the ping was successful, you will see the following response:

```
Reply from <IP Address>: bytes=xx time =xms TTL= xx
```

If the ping was unsuccessful, you will see the following response:

```
Request timed out.
```



Windows 95, 98, and NT do not support IPv6.

## Creating a New OS-9 Coreboot Image in Flash Memory

If you want to use ROM Ethernet services such as System State Debugging, you must create a new coreboot image. The coreboot image that was shipped with the reference board does not allow you to perform System State Debugging because the IP address in Flash ROM is set to “0.0.0.0”. You can create the coreboot image with an EPROM programmer.



Generally, re-creating the coreboot image is required only when system state debugging is desired.

### Making a Coreboot Image with an EPROM Programmer

Set the jumpers on the reference board as specified in the *GraphicsClient User's Manual* or *GraphicsClient Plus User's Manual* supplied by Applied Data Systems. In most cases you can use the default factory jumper settings.

Complete the following steps to make a coreboot image with an EPROM programmer:

- Step 1. From the Windows desktop, select **Start -> RadiSys -> Microware OS-9 for <product> -> Configuration Wizard**. Open the Wizard using the steps from the [Starting the Configuration Wizard](#) section.
- Step 2. Make any necessary changes to the coreboot settings.
- Step 3. Select **Configure -> Build Image** to display the Master Builder screen.
- Step 4. Select the **Coreboot Only Image** setting and click **Build**.
- Step 5. Click **Save As** to save the coreboot image to a directory of your choosing. If the directory does not exist, you will need to create it.
- Step 6. Transfer the coreboot image to the EPROM with the EPROM programmer. You will need to follow the documentation for the EPROM programmer to complete this step.
- Step 7. Install the FLASH device in socket U22 on the reference board.

## Compressing the Bootfile Image

OS-9 bootfiles can be compressed to allow more modules to be loaded into a bootfile; this can be useful if you plan on storing your image on a small FLASH part or a floppy disk.



The bootfile compression utility performs the compression at approximately a 2.5:1 ratio.

Complete the following steps to compress your image:

- Step 1. Verify that your coreboot contains the `uncompress` module. This module can be found in the pre-built ROM and coreboot images that were shipped with your Microware OS-9 product.



The `uncompress` module must be included in order for the compression to execute properly.

- Step 2. Open the Configuration Wizard and select **Configure** -> **Coreboot** -> **Main Configuration** from the main menu.
- Step 3. Select the **Bootfile Compression** tab. Verify that the **Include bootfile uncompress module** box is checked and select **OK**.
- Step 4. When you are ready to build the image, open the **Master Builder** dialog. Verify that the **Compress Bootfile** box is checked and then press **Build** to begin the installing the image.



# 2

## Board-Specific Reference

---

This chapter contains information that is specific to the INTEL SA-1100 Microprocessor Reference Platform (GraphicsClient) and the INTEL SA-1110 Microprocessor Reference Platform (GraphicsClient Plus) reference boards.

| <b>For information about...</b>                | <b>Go to this page...</b> |
|------------------------------------------------|---------------------------|
| <a href="#">Boot Options</a> .....             | 22                        |
| <a href="#">The Fastboot Enhancement</a> ..... | 24                        |
| <a href="#">OS-9 Vector Mappings</a> .....     | 27                        |
| <a href="#">GPIO Usage</a> .....               | 30                        |
| <a href="#">Port Specific Utilities</a> .....  | 31                        |

## Boot Options

Following are the default boot options for the reference board. You can select these by hitting the space bar when the Now Trying to Override Autobooters message appears on the console port when booting.

You can configure these booters by altering the `default.des` file at the following location:

```
MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/ROM
```

Booters can be configured to be either menu or auto booters. The auto booters automatically try and boot in order from each entry in the auto booter array. Menu booters from the defined menu booter array are chosen interactively from the console command line after getting the boot menu.

### Booting from FLASH

When the `romcnfg.h` has a ROM search list defined the options `ro` and `lr` appear in the boot menu. If no search list is defined N/A appears in the boot menu. If an OS9 bootfile is programmed into flash in the address range defined in `ports default.des` file the system can boot and run from flash.

|                 |                                                                             |
|-----------------|-----------------------------------------------------------------------------|
| <code>ro</code> | rom boot—the system runs from the FLASH bank.                               |
| <code>lr</code> | load to ram—the system copies the flash image into ram and runs from there. |

### Booting from PCMCIA ATA Card

The system can boot from a PC formatted PCMCIA hard card which resides in the PCMCIA slot.

|                   |                                                                                                                    |
|-------------------|--------------------------------------------------------------------------------------------------------------------|
| <code>ide0</code> | The file <code>os9kboot</code> is searched for in slot 0. If found it is copied to system RAM and runs from there. |
|-------------------|--------------------------------------------------------------------------------------------------------------------|

### Booting from Ethernet

The system can boot using the BootP protocol using either an Ethernet card or the on-board `eb` option.

|                 |                                                                                                                                                         |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>eb</code> | Ethernet boot—the selected Ethernet interface will use the <code>bootp</code> protocol to transfer a bootfile into RAM and the systems runs from there. |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|

### Booting over Serial Communications Port via kermit

The system can down-load a bootfile in binary form over its serial communication port at 115200 using the kermit protocol. The speed of this transfer depends of the size of the bootfile, but expect at least a 3 minute wait, dots will show the progress of the boot. The communications port is located at header J7 and uses the SA1100's SP1 UART.

|                  |                                                                                                                 |
|------------------|-----------------------------------------------------------------------------------------------------------------|
| <code>ker</code> | kermit boot—The <code>os9kboot</code> file is sent via the kermit protocol into system RAM and runs from there. |
|------------------|-----------------------------------------------------------------------------------------------------------------|

## Restart Booter

The restart booter allows a way to restart the bootstrap sequence.

`q` quit—quit and attempt to restart the booting process.

## Break Booter

The break booter allows entry to the system level debugger (if one exists). If the debugger is not in the system the system will reset.

`break` break—break and enter the system level debugger rombug.

Below is an xample boot session and message.

```
OS-9 Bootstrap for the ARM

ATA IDE disk found in socket 00
Now trying to Override autobooters.

BOOTING PROCEDURES AVAILABLE ----- <INPUT>

Boot embedded OS-9 in-place ----- <N/A>
Copy embedded OS-9 to RAM and boot ----- <N/A>
Boot from PCMCIA-1 IDE ----- <ide1>
Boot from PCMCIA-0 IDE ----- <ide0>
Load bootfile via kermit Download ----- <ker>
Restart the System ----- <q>
Enter system debugger ----- <break>

Select a boot method from the above menu: ide0

Wait for IDE drive ready.
IDE Model : ATA_FLASH
Number Heads : 0x0002
Total Cylinders : 0x03d8
Sectors Per Track : 0x0020

Checking Partitions : 0
Fat Type : 0x16
File Name : OS9KBOOT
File Size : 0x000fdeb0
Start Cluster : 0x00003a57
Reading Bootfile....
```

```
Boot Address : 0xc002c850
Boot Size : 0x000fdeb0
```

```
OS-9000 kernel was found.
A valid OS-9000 bootfile was found.
$
```

## The Fastboot Enhancement

The Fastboot enhancements to OS-9 provide faster system bootstrap performance to embedded systems. The normal bootstrap performance of OS-9 is attributable to its flexibility. OS-9 handles many different runtime configurations to which it dynamically adjusts during the bootstrap process.

The Fastboot concept consists of informing OS-9 that the defined configuration is static and valid. These assumptions eliminate the dynamic searching OS-9 normally performs during the bootstrap process and enables the system to perform a minimal amount of runtime configuration. As a result, a significant increase in bootstrap speed is achieved.

### Overview

The Fastboot enhancement consists of a set of flags that control the bootstrap process. Each flag informs some portion of the bootstrap code that a particular assumption can be made and that the associated bootstrap functionality should be omitted.

The Fastboot enhancement enables control flags to be statically defined when the embedded system is initially configured as well as dynamically altered during the bootstrap process itself. For example, the bootstrap code could be configured to query dip switch settings, respond to device interrupts, or respond to the presence of specific resources which would indicate different bootstrap requirements.

In addition, the Fastboot enhancement's versatility allows for special considerations under certain circumstances. This versatility is useful in a system where all resources are known, static, and functional, but additional validation is required during bootstrap for a particular instance, such as a resource failure. The low-level bootstrap code may respond to some form of user input that would inform it that additional checking and system verification is desired.

## Implementation Overview

The Fastboot configuration flags have been implemented as a set of bit fields. An entire 32-bit field has been dedicated for bootstrap configuration. This four-byte field is contained within the set of data structures shared by the ModRom sub-components and the kernel. Hence, the field is available for modification and inspection by the entire set of system modules (high-level and low-level). Currently, there are six bit flags defined with eight bits reserved for user-definable bootstrap functionality. The reserved user-definable bits are the high-order eight bits (31-24). This leaves bits available for future enhancements. The currently defined bits and their associated bootstrap functionality are listed below:

### B\_QUICKVAL

The `B_QUICKVAL` bit indicates that only the module headers of modules in ROM are to be validated during the memory module search phase. This causes the CRC check on modules to be omitted. This option is a potential time saver, due to the complexity and expense of CRC generation. If a system has many modules in ROM, where access time is typically longer than RAM, omitting the CRC check on the modules will drastically decrease the bootstrap time. It is rare that corruption of data will ever occur in ROM. Therefore, omitting CRC checking is usually a safe option.

### B\_OKRAM

The `B_OKRAM` bit informs both the low-level and high-level systems that they should accept their respective RAM definitions without verification. Normally, the system probes memory during bootstrap based on the defined RAM parameters. This allows system designers to specify a possible RAM range, which the system validates upon startup. Thus, the system can accommodate varying amounts of RAM. In an embedded system where the RAM limits are usually statically defined and presumed to be functional, however, there is no need to validate the defined RAM list. Bootstrap time is saved by assuming that the RAM definition is accurate.

### B\_OKROM

The `B_OKROM` bit causes acceptance of the ROM definition without probing for ROM. This configuration option behaves like the `B_OKRAM` option, except that it applies to the acceptance of the ROM definition.

### B\_1STINIT

The `B_1STINIT` bit causes acceptance of the first `init` module found during cold-start. By default, the kernel searches the entire ROM list passed up by the `ModRom` for `init` modules before it accepts and uses the `init` module with the highest revision number. In a statically defined system, time is saved by using this option to omit the extended `init` module search.

## B\_NOIRQMASK

The `B_NOIRQMASK` bit informs the entire bootstrap system that it should not mask interrupts for the duration of the bootstrap process. Normally, the `ModRom` code and the kernel cold-start mask interrupts for the duration of the system startup. However, some systems that have a well defined interrupt system (i.e. completely calmed by the `sysinit` hardware initialization code) and also have a requirement to respond to an installed interrupt handler during system startup can enable this option to prevent the `ModRom` and the kernel cold-start from disabling interrupts. This is particularly useful in power-sensitive systems that need to respond to “power-failure” oriented interrupts.

Some portions of the system may still mask interrupts for short periods during the execution of critical sections.

## B\_NOPARITY

If the RAM probing operation has not been omitted, the `B_NOPARITY` bit causes the system to not perform parity initialization of the RAM. Parity initialization occurs during the RAM probe phase. The `B_NOPARITY` option is useful for systems that either require no parity initialization at all or systems that only require it for “power-on” reset conditions. Systems that only require parity initialization for initial “power-on” reset conditions can dynamically use this option to prevent parity initialization for subsequent “non-power-on” reset conditions.

## Implementation Details

This section describes the compile-time and runtime methods by which the bootstrap speed of the system can be controlled.

### Compile-time Configuration

The compile-time configuration of the bootstrap is provided by a pre-defined macro (`BOOT_CONFIG`), which is used to set the initial bit-field values of the bootstrap flags. You can redefine the macro for recompilation to create a new bootstrap configuration. The new over-riding value of the macro should be established by redefining the macro in the `rom_config.h` header file or as a macro definition parameter in the compilation command.

The `rom_config.h` header file is one of the main files used to configure the `ModRom` system. It contains many of the specific configuration details of the low-level system. Below is an example of how you can redefine the bootstrap configuration of the system using the `BOOT_CONFIG` macro in the `rom_config.h` header file:

```
#define BOOT_CONFIG (B_OKRAM + B_OKROM + B_QUICKVAL)
```

Below is an alternate example showing the default definition as a compile switch in the compilation command in the makefile:

```
SPEC_COPTS = -dNEWINFO -dNOPARITYINIT -dBOOT_CONFIG=0x7
```

This redefinition of the `BOOT_CONFIG` macro results in a bootstrap method that accepts the RAM and ROM definitions without verification, and also validates modules solely on the correctness of their module headers.

## Runtime Configuration

The default bootstrap configuration can be overridden at runtime by changing the `rinf->os->boot_config` variable from either a low-level P2 module or from the `sysinit2()` function of the `sysinit.c` file. The runtime code can query jumper or other hardware settings to determine what user-defined bootstrap procedure should be used. An example P2 module is shown below.

If the override is performed in the `sysinit2()` function, the effect is not realized until after the low-level system memory searches have been performed. This means that any runtime override of the default settings pertaining to the memory search must be done from the code in the P2 module code.

```
#define NEWINFO
#include <rom.h>
#include <types.h>
#include <const.h>
#include <errno.h>
#include <romerrno.h>
#include <p2lib.h>

error_code p2start(Rominfo rinf, u_char *gblbs)
{
 /* if switch or jumper setting is set... */
 if (switch_or_jumper == SET) {
 /* force checking of ROM and RAM lists */
 rinf->os->boot_config &= ~(B_OKROM+B_OKRAM);
 }
 return SUCCESS;
}
```

## OS-9 Vector Mappings

This section contains the vector mappings for the OS-9 GraphicsClient implementation of the SA1100 and the OS-9 GraphicsClient Plus implementation of the SA1110.

The ARM standard defines exceptions 0x0-0x8. The OS-9 system maps these 1-1. External interrupts from vector 0x6 are expanded to the virtual vector range shown below by the `irq1100` module.

Vectors can be virtually remapped from a ROM at physical address 0, into DRAM at virtual address 0. This speeds up interrupt response time and is enabled by defining the first cache list entry as a sub 1M size.



Refer to the 1100/1110 hardware documentation for more information on individual sources.

Table 2-1 and Table 2-2 show the OS-9 IRQ assignment for the target board.

**Table 2-1.**

| <b>OS9 IRQ #</b> | <b>ARM Function</b>           |
|------------------|-------------------------------|
| 0x0              | Processor Reset               |
| 0x1              | Undefined Instruction         |
| 0x2              | Software Interrupt            |
| 0x3              | Abort on Instruction Prefetch |
| 0x4              | Abort on Data Access          |
| 0x5              | Unassigned/Reserved           |
| 0x6              | External Interrupt            |
| 0x7              | Fast Interrupt                |
| 0x8              | Alignment error               |

**Table 2-2.**

| <b>OS9 IRQ #</b> | <b>SA11X0 Specific Function (pic)</b>                 |
|------------------|-------------------------------------------------------|
| 0x40             | GPIO[0] Edge Detect (IRQ Input from the board's PIC.) |
| 0x41             | GPIO[1] Edge Detect                                   |
| 0x42             | GPIO[2] Edge Detect                                   |
| 0x43             | GPIO[3] Edge Detect                                   |
| 0x44             | GPIO[4] Edge Detect                                   |
| 0x45             | GPIO[5] Edge Detect                                   |
| 0x46             | GPIO[6] Edge Detect                                   |
| 0x47             | GPIO[7] Edge Detect                                   |
| 0x48             | GPIO[8] Edge Detect                                   |
| 0x49             | GPIO[9] Edge Detect                                   |
| 0x4a             | GPIO[10] Edge Detect                                  |
| 0x4b             | OR of GPIO edge detects 27 - 11                       |
| 0x4c             | LCD controller service request                        |
| 0x4d             | UDC service request (0)                               |
| 0x4e             | SDLC service request (1a)                             |
| 0x4f             | UART service request (1b) (SP1)                       |
| 0x50             | UART/HSSP service request (2)                         |
| 0x51             | UART service request (3) (SP3)                        |
| 0x52             | MCP service request (4a)                              |
| 0x53             | SSP service request (4b)                              |
| 0x54             | DMA controller channel 0                              |
| 0x55             | DMA controller channel 1                              |
| 0x56             | DMA controller channel 2                              |
| 0x57             | DMA controller channel 3                              |
| 0x58             | DMA controller channel 4                              |

Table 2-2.

| OS9 IRQ # | SA11X0 Specific Function (pic)                                                         |
|-----------|----------------------------------------------------------------------------------------|
| 0x59      | DMA controller channel 5                                                               |
| 0x5a      | OS timer 0                                                                             |
| 0x5b      | OS timer 1                                                                             |
| 0x5c      | OS timer 2                                                                             |
| 0x5d      | OS timer 3                                                                             |
| 0x5e      | One Hz clock tick                                                                      |
| 0x5f      | RTC als alarm register                                                                 |
| 0x60      | GPIO[11] Edge Detect (the vector 0x4b OR is broken out here to make each one distinct) |
| 0x61      | GPIO[12] Edge Detect                                                                   |
| 0x62      | GPIO[13] Edge Detect                                                                   |
| 0x63      | GPIO[14] Edge Detect                                                                   |
| 0x64      | GPIO[15] Edge Detect                                                                   |
| 0x65      | GPIO[16] Edge Detect                                                                   |
| 0x66      | GPIO[17] Edge Detect                                                                   |
| 0x67      | GPIO[18] Edge Detect                                                                   |
| 0x68      | GPIO[19] Edge Detect                                                                   |
| 0x69      | GPIO[20] Edge Detect                                                                   |
| 0x6a      | GPIO[21] Edge Detect                                                                   |
| 0x6b      | GPIO[22] Edge Detect                                                                   |
| 0x6c      | GPIO[23] Edge Detect                                                                   |
| 0x6d      | GPIO[24] Edge Detect                                                                   |
| 0x6e      | GPIO[25] Edge Detect                                                                   |
| 0x6f      | GPIO[26] Edge Detect                                                                   |
| 0x70      | GPIO[27] Edge Detect                                                                   |

Table 2-3 shows the board's Pic functions.

Table 2-3.

| OS9 IRQ # | Function (Board Pic)                     |
|-----------|------------------------------------------|
| 0xb1      | RESERVED                                 |
| 0xb2      | RESERVED                                 |
| 0xb3      | RESERVED                                 |
| 0xb4      | RESERVED                                 |
| 0xb5      | IRQ CAN1, (Graphics Client Plus version) |
| 0xb6      | RESERVED                                 |
| 0xb7      | PCMCIA slot 0 Ready/IRQ                  |
| 0xb8      | RESERVED                                 |
| 0xb9      | UCB 1200                                 |
| 0xba      | SMC 91C94 Ethernet                       |
| 0xbb      | RESERVED                                 |

Table 2-3.

| OS9 IRQ # | Function (Board Pic) |
|-----------|----------------------|
| 0xbc      | PCMCIA Card A detect |
| 0xbd      | RESERVED             |
| 0xbe      | Board Switch         |
| 0xbf      | IRQ SSP              |
| 0xc0      | IRQ BAT FAULT        |

### Fast Interrupt Vector (0x7)

The ARM4 defined fast interrupt (FIQ) mapped to vector 0x7 is handled differently by the OS-9 interrupt code and can not be used as freely as the external interrupt mapped to vector 0x6. To make fast interrupts as quick as possible for extremely time critical code, no context information is saved on exception and FIQs are never masked. This requires any exception handler to save and restore its necessary context if the FIQ mechanism is to be used. This requirement means that a FIQ handler's entry and exit points must be in assembly, as the C compiler will make assumptions about context. In addition, no system calls are possible unless a full C ABI context save has been done first. The OS-9 IRQ code for the SA11X0 has assigned all interrupts as normal external interrupts and the user must re-define a source as an FIQ to make use of this feature.

## GPIO Usage

Table 2-4 shows GPIO usage of the target board in an OS-9 system.



See the ADS *GraphicsClient User's Manual* or *Graphics Client Plus User's Manual* for available alternate pin functions.

Table 2-4.

| GPIO   | Signal Name | Direct | Description                                             |
|--------|-------------|--------|---------------------------------------------------------|
| GPIO0  | /IRQ        | Input  | Falling edge interrupt from external peripheral         |
| GPIO1  | SWITCH      | Input  | External signal to wake processor up during sleep mode. |
| GPIO2  | GREEN3      | Output | LCD Green bit 3 in 16 bit color mode=20                 |
| GPIO3  | GREEN4      | Output | LCD Green bit 4 in 16 bit color mode                    |
| GPIO4  | GREEN5      | Output | LCD Green bit 5 in 16 bit color mode                    |
| GPIO5  | RED0        | Output | LCD Red bit 0 in 16 bit color mode                      |
| GPIO6  | RED1        | Output | LCD Red bit 1 in 16 bit color mode                      |
| GPIO7  | RED2        | Output | LCD Red bit 2 in 16 bit color mode                      |
| GPIO8  | RED3        | Output | LCD Red bit 3 in 16 bit color mode                      |
| GPIO9  | RED4        | Output | LCD Red bit 4 in 16 bit color mode                      |
| GPIO10 | SSP_TXD     | Output | SSP Port transmit                                       |

Table 2-4. (Continued)

| GPIO   | Signal Name  | Direct | Description                            |
|--------|--------------|--------|----------------------------------------|
| GPIO11 | SSP_RXD      | Input  | SSP Port Receive                       |
| GPIO12 | SSP_SCLK     | Output | SSP Port Clock                         |
| GPIO13 | SSP_SFRM     | Output | SSP Port Frame                         |
| GPIO14 | CTS1         | Input  | CTS SA1100 uart 1<br>(not needed)      |
| GPIO15 | RTS1         | Output | RTS SA1100 uart 1<br>(not needed)      |
| GPIO16 | CTS2         | Input  | CTS SA1100 uart 2<br>(not needed)      |
| GPIO17 | RTS2         | Output | RTS SA1100 uart 2<br>(not needed)      |
| GPIO18 | CTS3         | Input  | CTS SA1100 uart 3<br>(not needed)      |
| GPIO19 | RTS3         | Output | RTS SA11X0 uart 3<br>(not needed)      |
| GPIO20 | LED0         | Output | SMD LED D3 on board                    |
| GPIO21 | LED1         | Output | SMD LED D2 on board                    |
| GPIO22 | LED2         | Output | SMD LED D1 on board                    |
| GPIO23 | IRDA_ON      | Output | 0 IRDA On, 1 IRDA Off                  |
| GPIO24 | LED4/PNL_ENA | In/Out | External GPIO on J7, P38, Panel Enable |
| GPIO25 | LED5         | In/Out | External GPIO on J7, P36               |
| GPIO26 | LED6         | In/Out | External GPIO on J7, P34               |
| GPIO27 | LED7         | In/Out | External GPIO on J7, P32               |

## GPIO Interrupt Polarity

When GPIO's are used as interrupt sources, the `_PIC_ENABLE()` function will set default polarity to rising edge (GRER) along with enabling the interrupt at the SA11X0 PIC. If falling edge is required, software must assert the appropriate bit in the GFER and negate the corresponding bit in the GRER.

## Port Specific Utilities

The following port specific utilities are included:

- `pcmcia`
- `pflash`
- `touch_cal`
- `ucbtouch`

## pcmcia

### Syntax

```
pcmcia [<opts>]
```

### Options

|     |                                      |
|-----|--------------------------------------|
| -s= | socket: socket [default all sockets] |
| -d  | de-iniz socket(s)                    |
| -i  | iniz socket(s)                       |
| -v  | verbose mode                         |
| -x  | dump CIS/Config information          |
| -?  | Print this help message              |

### Description

`pcmcia` provides the ability to initialize or deinitialize a PCMCIA card after the system has booted. It also displays a PCMCIA card's CIS structure.

### Example

```
$ pcmcia -x -s=0
ATA IDE disk found in socket0
Dump CIS Window for Socket #0
 Addr 0 1 2 3 4 5 6 7 8 9 A B C D E F 0 2 4 6 8 A C E

28000000 01 03 d9 01 ff 1c 04 03 d9 01 ff 18 02 df 01 20
28000020 04 01 4e 00 01 15 2b 04 01 56 49 4b 49 4e 47 20 ..N...+..VIKING
28000040 43 4f 4d 50 4f 4e 45 4e 54 53 20 20 20 20 20 20 COMPONENTS
28000060 20 20 00 43 46 20 41 54 41 20 00 56 2e 31 30 32 .CF ATA .V.102
28000080 00 ff 21 02 04 01 22 02 01 01 22 03 02 04 5f 1a ..!..."..._.
280000a0 05 01 03 00 02 0f 1b 09 c0 40 a1 21 55 55 08 00@.!UU..
280000c0 22 1b 06 00 01 21 b5 1e 35 1b 0b c1 41 99 21 55 "...!..5...A.!U
280000e0 55 64 f0 ff ff 22 1b 06 01 01 21 b5 1e 35 1b 0d Ud..."...!..5..
28000100 82 41 98 ea 61 f0 01 07 f6 03 01 ee 22 1b 06 02 .A..a....."....
28000120 01 21 b5 1e 35 1b 0d 83 41 98 ea 61 70 01 07 76 .!..5...A..ap..v
28000140 03 01 ee 22 1b 06 03 01 21 b5 1e 35 14 00 ff ff ...".....!..5....
28000160 ff
28000180 ff
280001a0 ff
280001c0 ff
280001e0 ff
Dump Config Window for Socket #0
 Addr 0 1 2 3 4 5 6 7 8 9 A B C D E F 0 2 4 6 8 A C E

28000200 43 00 02 00 00 00 00 00 00 00 00 00 00 00 00 00 C.....
28000220 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
28000240 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
28000260 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
28000280 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
280002a0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
280002c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```



## pflash

### Syntax

```
pflash [options]
```

### Options

|                 |                                                                                   |
|-----------------|-----------------------------------------------------------------------------------|
| -f [=] filename | input filename                                                                    |
| -eu             | erase used space only (default)                                                   |
| -ew             | erase whole flash                                                                 |
| -ne             | don't erase flash                                                                 |
| -r              | program resident flash (default)                                                  |
| -p0             | program PCMCIA slot 0                                                             |
| -p1             | program PCMCIA slot 1                                                             |
| -ncis           | don't emit cis for PCMCIA flash cards                                             |
| -b [=] addr     | specify base address of flash (hex) for part identification (replaces -r,-p0,-p1) |
| -s [=] addr     | specify write/erase address of flash(hex) defaults to base address                |
| -u              | leave flash unlocked                                                              |
| -i              | print out information on flash                                                    |
| -nv             | don't verify erase or write                                                       |
| -q              | no progress indicator                                                             |

### Description

The pflash utility allows the programming of Intel Strata Flash parts. The primary use will be in the burning of the OS-9 ROM image into the on-board flash parts at U25/U26. This allows for booting using the lr/bo booters and allows for booting with out a PCMCIA card. The pflash utility also can be used to burn OS-9 ROM images into Intel Value Series PCMCIA cards, which internally use StrataFlash parts. This allows for booting using a PCMCIA slot and the f0 booter.

### Example

In this example an OS-9 ROM image was built and placed on an ATA PCMCIA card. After booting using the PCMCIA card, the image can be burned into the on-board Flash.

```
$ pflash -f=/mhc1/os9kboot
```

```
Unlocking Device
```

```
Erasing
```

```
Programming
```

```
Locking Device
```

```
$
```

```
<<< Reset the Board via SW1 >>>
```

```
OS-9 Bootstrap for the ARM (Edition 65)
```

```
ATA IDE disk found in socket 00
```

```
Now trying to Override autobooters.
```

```
Press the spacebar for a booter menu
```

```
BOOTING PROCEDURES AVAILABLE ----- <INPUT>
```

```
Boot embedded OS-9 in-place ----- <bo>
```

```
Copy embedded OS-9 to RAM and boot ---- <lr>
```

```
Boot from PCMCIA-0 IDE ----- <ide0>
```

```
Restart the System ----- <q>
```

```
Select a boot method from the above menu: lr
```

```
Now searching memory ($08000000 - $08ffffff) for an OS-9000 Kernel...
```

```
An OS-9 kernel was found at $08000000
```

```
A valid OS-9 bootfile was found.
```

```
$
```

## touch\_cal

### Syntax

```
touch_cal <options>
```

### Options

- |                      |                                                        |
|----------------------|--------------------------------------------------------|
| -f [=] <name>        | Output filename                                        |
| -c                   | Only run calibration if output filename does not exist |
| -m [=] <font_module> | Use given UCM font module to display text              |

### Description

The `touch_cal` utility will present a text message on the LCD screen as well as points for the user to press. After the points are pressed, the protocol module `mp_ucb1200` will be updated with the new calibration information.

### Example

```
$ touch_cal
Found touch screen device '/ucb_touch/mp_ucb1200'
```

## ucbtouch

### Syntax

```
ucbtouch <>
```

### Description

The `ucbtouch` utility prints the raw x,y and pressure values at a set sample rate.

Press the touch screen and observe the output on your console. The utility is helpful in determining whether your touch screen is connected properly.

### Example

```
$ ucbtouch
Touch[00000]: Touch=0x30c3 X1=00328 Y1=00321 P= 28 X=329 Y=322
Touch[00001]: Touch=0x30c3 X1=00329 Y1=00325 P= 28 X=330 Y=326
Touch[00002]: Touch=0x30c3 X1=00329 Y1=00321 P= 28 X=330 Y=322
Touch[00003]: Touch=0x30c3 X1=00329 Y1=00321 P= 29 X=330 Y=322
Touch[00004]: Touch=0x30c3 X1=00329 Y1=00319 P= 29 X=330 Y=320
Touch[00005]: Touch=0x30c3 X1=00329 Y1=00321 P= 28 X=330 Y=322
Touch[00006]: Touch=0x30c3 X1=00329 Y1=00327 P= 28 X=330 Y=328
Touch[00007]: Touch=0x30c3 X1=00329 Y1=00321 P= 28 X=330 Y=322
Touch[00008]: Touch=0x30c3 X1=00329 Y1=00321 P= 29 X=330 Y=322
Touch[00009]: Touch=0x30c3 X1=00329 Y1=00322 P= 28 X=330 Y=323
Touch[00010]: Touch=0x30c3 X1=00329 Y1=00319 P= 28 X=0 Y=0
Touch[00011]: Touch=0x30c3 X1=00328 Y1=00321 P= 28 X=-1 Y=2
Touch[00012]: Touch=0x30c3 X1=00329 Y1=00315 P= 28 X=0 Y=-4
Touch[00013]: Touch=0x30c3 X1=00329 Y1=00322 P= 29 X=0 Y=3
```



# A

## Board-Specific Modules

---

This chapter describes the modules specifically written for the target board.

| <b>For information about...</b>                 | <b>Go to this page...</b> |
|-------------------------------------------------|---------------------------|
| <a href="#">Low-Level System Modules</a> .....  | 40                        |
| <a href="#">High-Level System Modules</a> ..... | 41                        |

## Low-Level System Modules



For a complete list of OS-9 modules common to all boards, refer to the OS-9 *Device Descriptor and Configuration Module Reference* manual.

The following low-level system modules are tailored specifically for the ADS SA1100 GraphicsClient and ADS SA1110 GraphicsClient Plus platforms. The functionality of these modules can be altered through changes to the configuration data module (cnfgdata). [Table A-1](#) provides a list and brief description of the modules.

These modules can be found in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMD5/BOOTOBS/ROM

**Table A-1. Board-Specific Low-Level System Modules**

| Module Name | Description                                                     |
|-------------|-----------------------------------------------------------------|
| cnfgdata    | Contains the low-level configuration data.                      |
| cnfgfunc    | Provides access services to cnfgdata data.                      |
| commcnfg    | Inits communication port defined in cnfgdata.                   |
| conscnfg    | Inits console port defined in cnfgdata.                         |
| ide         | IDE boot support module. PCMCIA compatible.                     |
| io1100      | Provides polled serial driver support for the low-level system. |
| llcis       | Inits the PCMCIA interface including cards.                     |
| lle509      | Provides low-level ethernet services via 3COM PCMCIA card.      |
| portmenu    | Inits booters defined in the cnfgdata.                          |
| romcore     | Board specific initialization code.                             |
| splash      | Provides way to init LCD screen with a compressed image.        |
| tmr1_1100   | Provides low-level timer services via time base register.       |
| usedebug    | Inits low-level debug interface to RomBug, SNDF, or none.       |

The following low-level system modules provide generic services for OS9000 Modular ROM. [Table A-2](#) provides a list and brief description of the modules.

These modules can be found in the following directory:

MWOS/OS9000/ARMV3/CMD5/BOOTOBSJ/ROM

**Table A-2. Generic Services Low-Level System Modules**

| Module Name | Description                                                       |
|-------------|-------------------------------------------------------------------|
| bootsys     | Booter registration service module.                               |
| console     | Provides console services.                                        |
| dbgentry    | Initiates debugger entry point for system use.                    |
| dbgserve    | Provides debugger services.                                       |
| excpction   | Provides low-level exception services.                            |
| fdman       | OS-9 RBF file system ROM-based service                            |
| flshcach    | Provides low-level cache management services.                     |
| hlproto     | Provides user level code access to protoman.                      |
| llbootp     | Booter which provides bootp services.                             |
| llip        | Provides low-level IP services.                                   |
| llslip      | Provides low-level SLIP services.                                 |
| lltcp       | Provides low-level TCP services.                                  |
| lludp       | Provides low-level UDP services.                                  |
| llkermit    | Booter which uses kermit protocol.                                |
| notify      | Provides state change information for use with LL and HL drivers. |
| override    | Booter which allows choice between menu and auto booters.         |
| parser      | Provides argument parsing services.                               |
| pcman       | Booter which reads MS-DOS file system.                            |
| protoman    | Protocol management module.                                       |
| restart     | Booter which cause a soft reboot of system.                       |
| romboot     | Booter which allows booting from ROM.                             |
| rombreak    | Booter which calls the installed debugger.                        |
| rombug      | Low-level system debugger.                                        |
| sndp        | Provides low-level system debug protocol.                         |
| srecord     | Booter which accepts S-Records.                                   |
| swtimer     | Provides timer services via software loops.                       |

## High-Level System Modules

The following OS-9 system modules are tailored specifically for the ADS SA1100 GraphicsClient and ADS SA1110 GraphicsClient Plus boards and peripherals. Unless otherwise specified, each module is located in a file of the same name in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMD5/BOOTOBSJ

## CPU Support Modules

These files are located in the following directory:

MWOS/OS9000/ARMV4/CMD5/BOOTOBS

|         |                                                                                                                |
|---------|----------------------------------------------------------------------------------------------------------------|
| kernel  | The kernel provides all basic services for the OS-9 system.                                                    |
| cache   | Provides cache control for the CPU cache hardware. The cache module is in the file <code>cach1100</code> .     |
| fpu     | Provides software emulation for floating point instructions.                                                   |
| ssm     | The System Security Module provides support for the Memory Management Unit (MMU) on the CPU.                   |
| vectors | Provides interrupt service entry and exit code. The vectors module is found in the file <code>vect110</code> . |

## System Configuration Modules

These files are located in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMD5/BOOTOBS/INITS

|        |                                                                      |
|--------|----------------------------------------------------------------------|
| init   | Descriptor module with high level system initialization information. |
| nodisk | Same as <code>init</code> , but used in a diskless system.           |

## Interrupt Controller Support

This module provides extensions to the vectors module by mapping the single interrupt generated by an interrupt controller into a range of pseudo vectors, which are recognized by OS-9 as extensions to the base CPU exception vectors.

The mappings are described in Chapter 1.

|         |                                                                                                                  |
|---------|------------------------------------------------------------------------------------------------------------------|
| irq1100 | P2module that provides interrupt acknowledge and dispatching support for the SA1100 pic.                         |
| irqtc   | P2module that provides interrupt acknowledge and dispatching support for the board pic (vector range 0xB1-0xC0). |

## Real Time Clock

|         |                                                                          |
|---------|--------------------------------------------------------------------------|
| rtc1100 | Driver that provides OS-9 access to the SA1100 on-board real time clock. |
|---------|--------------------------------------------------------------------------|

## Ticker

|        |                                                                                    |
|--------|------------------------------------------------------------------------------------|
| tk1100 | Driver that provides the system ticker based on the SA11X0 Operating System Timer. |
|--------|------------------------------------------------------------------------------------|

## Abort Handler

|       |                                                                                                                                   |
|-------|-----------------------------------------------------------------------------------------------------------------------------------|
| abort | P2module which provides a way to enter the system-state debugger via the GPIO[0] interrupt triggered by the board's switch S1, 1. |
|-------|-----------------------------------------------------------------------------------------------------------------------------------|

## Generic IO Support Modules (File Managers)

These files are located in the following directory:

MWOS/OS9000/ARMV3/CMDS/BOOTOBS

|         |                                                                              |
|---------|------------------------------------------------------------------------------|
| ioman   | Provides generic io support for all IO device types.                         |
| scf     | Provides generic character device management functions.                      |
| rbf     | Provides generic block device management functions for OS-9 specific format. |
| pcf     | Provides generic block device management functions for MS-DOS FAT format.    |
| spf     | Provides generic protocol device management function support.                |
| mfm     | Provides generic graphics device support for MAUI®.                          |
| pipeman | Provides a memory FIFO buffer for communication.                             |

## Pipe Descriptor

This file is located in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMDS/BOOTOBS/DESC

|      |                                                                                                |
|------|------------------------------------------------------------------------------------------------|
| pipe | Pipeman descriptor that provides a RAM based FIFO which can be used for process communication. |
|------|------------------------------------------------------------------------------------------------|

## RAM Disk Support

|     |                                                             |
|-----|-------------------------------------------------------------|
| ram | RBF driver which provides a RAM based virtual block device. |
|-----|-------------------------------------------------------------|

### Descriptors for Use with RAM

These files are located in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMDS/BOOTOBS/DESC/RAM

|       |                                                                        |
|-------|------------------------------------------------------------------------|
| r0    | RBF descriptor which provides access to a ram disk.                    |
| r0.dd | Same as r0 except with module name dd (for use as the default device). |

## Serial and Console Devices

sc1100 SCF driver which provides serial support the SA11X0's SP1 and SP3 ports when configured as UARTS.

### Descriptors for Use with sc1100

term1/t1 Descriptor modules for use with sc11X0 and SP1.  
Board header:J7  
Default Baud Rate:19200  
Default Parity:None  
Default Data Bits:8  
Default Handshake:Software

term3/t3 Descriptor modules for use with sc11X0 and SP3.  
Board header:J2  
Default Baud Rate:115200  
Default Parity:None  
Default Data Bits:8  
Default Handshake:Software

sc16550 SCF driver which provides serial support for a 16550 compatible modem card.

### Descriptors for Use with sc16550

t0m Descriptor modules for use with the external PCMCIA card  
sc16550 Board header:J11 PCMCIA slot  
Default Baud Rate:9600  
Default Parity: None  
Default Data Bits:8  
Default Handshake:Software

### Descriptors for Use with scllio

vcons/term Descriptor modules for use with scllio in conjunction with a low-level serial driver. Port configuration and set up follows what is configured in cnfgdata for the console port. It is possible for scllio to communicate with a true low-level serial device driver like io1100, or with an emulated serial interface provided by iovcons. See the OEM manual for more information.

## PCMCIA Support for IDE Type Devices

`rb1003` RBF/PCF driver that provides driver support for IDE/EIDE devices. This driver is used to provide disk support for PCMCIA ATA FLASH.

### Descriptors for Use with `rb1003`

`hc1/hc1fmt` and `hc1.ddRBF` Descriptor modules for use with PCMCIA slot #0

Board header: J11

`hc1fmt`: format enabled

`hc1.dd`: module name of `dd`

`mhc1/mhc1.ddPCF` Descriptor modules for use with PCMCIA slot #0

Board header: J11

`mhc1.dd`: module name of `dd`

## PCMCIA Support for 3COM Ethernet Card

These files are located in the following directory:

`MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMD5/BOOTOBS/SPF`

`spe509_pcm` SPF driver to support ethernet for a 3COM EtherLink III PCMCIA card.

### Descriptors for Use with `spe509_pcm`

`spe30` SPF descriptor module for use with PCMCIA slot #0 (J11)

### Network Configuration Modules

`inetdb/inetdb2/rpcdb`

## SMC91C94 Ethernet Support

These files are located in the following directory:

`MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMD5/BOOTOBS/SPF`

`sp91c94` SPF driver to support ethernet for the SMC91C94 chip.

### Descriptor for Use with `sp91c94`

`spsm0` SPF descriptor module for use with SMC91C94 at J9.

### Network Configuration Modules

`inetdb/inetdb2/rpcdb`

## UCB1200 Support Modules

These files are located in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMDS/BOOTOBS/SPF

`spucb1200` SPF driver that supports the on-board Phillips UCB1200 chip. This device communicates to the SA11X0 over SP4 using MCP. The `spucb1200` will work with UCB1100, UCB1200, and UCB1300 devices.

### Descriptors for Use with `spucb1200`

`ucb` SPF descriptor module that provides access to UCB1200.

`ucb_touch` SPF descriptor module used with the touch screen.

## Maui Graphical Support Modules

These files are located in the following directory:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT/CMDS/BOOTOBS/MAUI

`gx_sa1100` MFM MAUI driver module with support for the board's LCD panel.

### Descriptors for Use with `gx_sa1100`

`gfx` MFM MAUI descriptor module for the board's LCD.

`sd_ucb 1200` MFM MAUI driver module that provides PCM/mu-law sound support via the `ucb1200`.

### Descriptors for Use with `sd_ucb1200`

`snd` MFM MAUI descriptor module for UCB1200 sound functions.

### MAUI Configuration Modules

`cdb` MAUI configuration data base module.

`cdb_ptr` Serial mouse configuration data base module.

`cdb_touch` Touch screen configuration data base module.

### MAUI Protocol Modules

`mp_kybrd` Keyboard protocol module

`mp_msptr` Serial mouse protocol module.

`mp_ucb1200` `ucb1200` protocol module.

# B

## MAUI Driver Descriptions

---

This chapter provides MAUI driver descriptions. It includes the following sections:

| <b>For information about...</b>                                    | <b>Go to this page...</b> |
|--------------------------------------------------------------------|---------------------------|
| <a href="#">GraphicsClient Objects</a> .....                       | 48                        |
| <a href="#">GX_SA1100 LCD Graphic Driver Specification</a> .....   | 48                        |
| <a href="#">SD_UCB1200 Sound Driver Specification</a> .....        | 51                        |
| <a href="#">SPUCB1200 driver for the UCB1200 Codec</a> .....       | 54                        |
| <a href="#">MP_UCB1200 MAUI Touch screen Protocol Module</a> ..... | 56                        |

## GraphicsClient Objects

This package provides object-level support for the Intel GraphicsClient reference board. The port directory is at the following location:

MWOS/OS9000/ARMV4/PORTS/GRAPHICSCLIENT

### MAUI objects

|                                             |                                               |
|---------------------------------------------|-----------------------------------------------|
| <code>cdb</code>                            | Lists the devices on the system.              |
| <code>mp_mspttr</code>                      | Serial mouse protocol module.                 |
| <code>mp_ucb1200</code>                     | Touch screen protocol module for the UCB1200. |
| <code>gfx</code> and <code>gx_sa1100</code> | LCD graphics descriptor and driver.           |

## GX\_SA1100 LCD Graphic Driver Specification

This section describes the hardware specification of the StrongARM SA11X0 LCD driver (named `gx_sa1100`) and descriptor (named `gfx`). The hardware sub-type defines the board configuration. This specification should be used with the MAUI Graphics Device API.

### Board Ports

This driver is used in the following example board StrongArm ports.

The GraphicsClient board uses a Sharp LQ64D341 18 bpp color (16 used), TFT, with a resolution of 640x480 single panel. This panel is connected to the GraphicsClient with one of several possible cables:

- 8 bpp - most common to date
- RGB 565 - next most common
- RGB 655
- RGB 556

The GraphicsClient board can support an LCD panel, but does not typically ship with one. For this reason the GraphicsClient port does not build this driver. If the user did connect a LCD panel to this board, simply copy the makefiles from one of the other ports into the GraphicsClient port.

## Device Capabilities

Information about the hardware capabilities is determined by calling `gfx_get_dev_cap()`. The hardware sub-type defines the board configuration. This function returns a data structure formatted as shown in [Table B-1](#). See `GFX_DEV_CAP` for more information about this data structure.

**Table B-1. `gfx_get_dev_cap()` Data Structure**

| Member Name                | Description                               | Value                                                              |
|----------------------------|-------------------------------------------|--------------------------------------------------------------------|
| <code>hw_type</code>       | Hardware type (embedded in driver)        | SA1100 LCD Controller                                              |
| <code>hw_subtype</code>    | Hardware subtype (embedded in descriptor) | Graphicsclient 8 bit color LCD, or GraphicsClient 16 bit color LCD |
| <code>sup_vpmix</code>     | Supports viewport mixing                  | FALSE                                                              |
| <code>sup_extvid</code>    | Supports external video as a backup       | FALSE                                                              |
| <code>sup_bkcol</code>     | Supports background color                 | FALSE                                                              |
| <code>sup_vptrans</code>   | Supports viewport transparency            | FALSE                                                              |
| <code>sup_vpinten</code>   | Supports viewport intensity               | FALSE                                                              |
| <code>sup_sync</code>      | Supports retrace synchronization          | FALSE                                                              |
| <code>num_res</code>       | Number of display resolutions             | 1                                                                  |
| <code>res_info</code>      | Array of display resolution information   | See Display Resolution table                                       |
| <code>dac_depth</code>     | Depth of the DAC in bits                  | 12                                                                 |
| <code>num_cm</code>        | Number of coding methods                  | 1                                                                  |
| <code>cm_info</code>       | Array of coding method information        | See Coding Methods table                                           |
| <code>sup_viddecode</code> | Supports video decoding into a drawmap    | FALSE                                                              |

## Display Resolution

The display resolution is configured by the descriptor and can be changed to support LCD panels of different sizes. The driver is only designed to support one resolution at a time. That resolution is specified by the descriptor. Modify the `DEFAULT_RES` macro in `mfm_desc.h` to change the resolution. If you change the resolution, you must also change all of the LCD timing fields as well.

**Table B-2. Display Specifications**

| Board           | Width | Height | Refresh Rate | Interlace Mode            | Aspect Ratio X:Y |
|-----------------|-------|--------|--------------|---------------------------|------------------|
| Graphics-Client | 640   | 480    | 0*           | <code>GFX_INTL_OFF</code> | 1:1              |

\*Refresh rate is determined by timing specified in descriptor. The devcap is not automatically update to reflect this.

## Coding Methods

The coding method is also configured by the descriptor and can be changed to support b/w and color LCD panels. The coding method can be selected in the descriptor by simply specifying the coding method in the `DEFAULT_CM` macro in `mfm_desc.h`.

This driver was verified on the GraphicsClient with both a 8-bit and 565 cables. The maximal coding method supported by SA11X0 LCD Controller is 16 bpp.

**Table B-3. Coding Method Description**

| Board                                        | Coding Method                                                                 | CLUT-Based | X,Y Multipliers | Palette Color Types        |
|----------------------------------------------|-------------------------------------------------------------------------------|------------|-----------------|----------------------------|
| Graphics-Client<br>(8-bit cable)             | <code>GFX_CM_8BIT</code>                                                      | TRUE       | 1,1             | <code>GFX_COLOR_RGB</code> |
| Graphics-Client<br>(16-bit cable)            | <code>GFX_CM_565</code><br><code>GFX_CM_655</code><br><code>GFX_CM_556</code> | FALSE      | 1,1             | NA                         |
| No current hardware implementation available | <code>GFX_CM_4BIT</code>                                                      | TRUE       | 1,1             | <code>GFX_COLOR_RGB</code> |

## Viewport Complexity

The driver supports one active viewport at a time. The application can create multiple viewports and stack them. The viewport must be aligned with, and the same size as the display. Display drawmaps must be the same size as the viewport.

## Memory

Applications are expected to request graphics memory from the driver. The driver allocates memory from the system as needed. It requests this memory from color 0x80. This memory (specified in the init module) is located at the bottom of 16 MB DRAM address space and is marked as non-cached.

## Location

This driver's source is located in the following directory:

```
SRC/DPIO/MFM/DRVR/GX_SA1100
```

This driver's makefiles are located in the following directory:

```
OS9000/ARMV4/PORTS/GRAPHICSCLIENT/MAUI/GX_SA1100
```

This directory contains the makefiles and descriptor header file to build the descriptor(s) and driver(s) (not all packages include driver source) for the StrongARM reference platform.

This directory contains:

```
makefile Calls each of the other makefiles in this directory
drvr.mak Builds the driver
desc.mak Builds the descriptor(s)
mfm_desc.h Defines values for all modifiable fields of the descriptor(s)
```

### Build the Driver

The driver source is located in `SRC/DPIO/MFM/DRVR/GX_SA1100`. To build the driver, use the following commands:

```
cd OS9000/ARMV4/PORTS/GRAPHICSCLIENT/MAUI/GX_SA1100
os9make -f drvr.mak
```

### Build the Descriptor

To build a new descriptor, modify `mfm_desc.h`, and use the following commands to compile:

```
cd OS9000/ARMV4/PORTS/GRAPHICSCLIENT/MAUI/GX_SA1100
os9make -f desc.mak
```

To build both the driver and the descriptor you can specify `os9make` with no parameters.

## SD\_UCB1200 Sound Driver Specification

This section describes the hardware specifications for the Philips UCB1200 driver `sd_ucb1200`. The hardware sub-type defines the board configuration. This specification should be used in conjunction with the MAUI Sound Driver Interface.

This driver works in conjunction with the `spucb1200` driver.

### Device Capabilities

Information about the hardware capabilities is determined by calling `_os_gs_snd_devcap()`. This function returns a data structure formatted as in the following table. See `SND_DEV_CAP` for more information about this data structure.

**Table B-4. Data Returned in `SND_DEV_CAP`**

| Member Name                | Value                          | Description                     |
|----------------------------|--------------------------------|---------------------------------|
| <code>hw_type</code>       | <code>CS4231</code>            | Hardware type                   |
| <code>hw_subtype</code>    | <code>CS4231A</code>           | Hardware sub-type               |
| <code>sup_triggers</code>  | <code>SND_TRIG_ANY</code>      | Supported triggers              |
| <code>play_lines</code>    | <code>SND_LINE_SPEAKER</code>  | Play gain/mix lines             |
| <code>record_lines</code>  | <code>SND_LINE_MIC</code>      | Record gain/mix lines           |
| <code>sup_gain_cmds</code> | <code>SND_GAIN_CMD_MONO</code> | Mask of supported gain commands |

Table B-4. Data Returned in SND\_DEV\_CAP (Continued)

| Member Name   | Value                             | Description                    |
|---------------|-----------------------------------|--------------------------------|
| num_gain_caps | 2                                 | Number of SND_GAIN_CAPs        |
| gain_caps     | See Gain Capabilities Array       | Pointer to SND_GAIN_CAP array  |
| num_rates     | 30                                | Number of sample rates         |
| sample_rates  | See Sample Rates                  | Pointer to sample rate array   |
| num_chan_info | 1                                 | Number of channel info entries |
| channel_info  | See Number of Channels            | Pointer to channel info array  |
| num_cm        | 3                                 | Number of coding methods       |
| cm_info       | See Encoding and Decoding Formats | Pointer to coding method array |

## Gain Capabilities Array

The following tables show the various gain capabilities for the Philips UCB1200. This information is pointed to by the gain\_cap member of the SND\_DEV\_CAP data structure. Refer to SND\_GAIN\_CAP for more information about this data structure. This driver allows control of following individual physical gain controls:

Table B-5. Individual Gain Controls

|                  |                    |
|------------------|--------------------|
| SND_LINE_SPEAKER | Output Attenuation |
| SND_LINE_MIC     | Microphone Gain    |

The following tables detail the various individual gain capabilities:

Table B-6. Speaker Gain Enable

| Member Name   | Value             | Step    | HW  | Level    | Comments      |
|---------------|-------------------|---------|-----|----------|---------------|
| lines         | SND_LINE_SPEAKER  | 0-3     | 31  | -69 dB   | default_level |
| sup_mute      | TRUE              | 4-7     | 30  | -66.8 dB |               |
| default_type  | SND_GAIN_CMD_MONO | 8-11    | 29  | -64.7 dB |               |
| default_level | SND_LEVEL_MAX     | 12-15   | 28  | -62.5 dB |               |
| zero_level    | SND_LEVEL_MIN     | ...     | ... | ...      |               |
| num_steps     | 32                | 112-115 | 3   | -6.5 dB  |               |
| step_size     | 216               | 116-119 | 2   | -4.3 dB  |               |
| mindb         | -6900             | 120-123 | 1   | -2.2 dB  |               |
| maxdb         | 0                 | 124-127 | 0   | 0.0 dB   | zero_level    |

Table B-7. Mic Gain Enable

| Member Name   | Value             | Step    | HW  | Level   | Comments      |
|---------------|-------------------|---------|-----|---------|---------------|
| lines         | SND_LINE_MIC      | 0-3     | 0   | 0 dB    | zero_level    |
| sup_mute      | FALSE             | 4-7     | 1   | 0.7 dB  |               |
| default_type  | SND_GAIN_CMD_MONO | ...     | ... | ...     | ...           |
| default_level | SND_LEVEL_MAX     | 64-67   | 16  | 11.3 dB | default_level |
| zero_level    | SND_LEVEL_MIN     | ...     | ... | ...     | ...           |
| num_steps     | 32                | 112-115 |     | 20.4 dB |               |
| step_size     | 70                | 116-119 | 29  | 21.1 dB |               |
| mindb         | 0                 | 120-123 | 30  | 21.8 dB |               |
| maxdb         | 2250              | 124-127 | 31  | 22.5 dB |               |

## Sample Rates

Following is an abbreviated list of the supported sample rates for the UCB1200. Below is a formula to derive valid sample rates:

$$\text{sample\_rate} = 11981000 / (32 * i), \text{ where } 8 < i < 128$$

This information is pointed to by the `sample_rates` member of the `SND_DEV_CAP` data structure.

Table B-8. Sample Rate (Hz)

|       |       |       |       |       |
|-------|-------|-------|-------|-------|
| 2948  | 3941  | 4926  | 5942  | 6933  |
| 7966  | 8914  | 9852  | 10697 | 11700 |
| 12910 | 13866 | 14976 | 15600 | 17828 |
| 18720 | 19705 | 20800 | 22023 | 23400 |
| 24960 | 26743 | 28800 | 31200 | 34036 |
| 37440 | 41600 | 46801 | 53486 | 62401 |

## Number of Channels

The following table shows the different supported number of channels for the Philips UCB1200. The first entry in the table is the default number of channels. This information is pointed to by the `channel_info` member of the `SND_DEV_CAP` data structure.

Table B-9. Number of Channels

| Channels | Description |
|----------|-------------|
| 1        | Mono        |

## Encoding and Decoding Formats

The following table shows the supported encoding and decoding formats for the Philips UCB1200. The first entry in the table is the default format. This information is pointed to by the `cm_info` member of the `SND_DEV_CAP` data structure.

**Table B-10. Encoding and Decoding Formats**

| Coding Method                                                    | Sample Size | Boundary Size | Description                                           |
|------------------------------------------------------------------|-------------|---------------|-------------------------------------------------------|
| <code>SND_CM_PCM_ULAW</code>                                     | 8           | 2             | 8 bit u-Law commanded                                 |
| <code>SND_CM_PCM_SLINEAR</code><br><code>SND_CM_LSBYTE1ST</code> | 16          | 4             | 16 bit Linear (two's complement)<br>little-endian     |
| <code>SND_CM_PCM_SLINEAR</code>                                  | 16          | 4             | 16 bit Linear signed (two's complement)<br>big-endian |

## SPUCB1200 driver for the UCB1200 Codec

This document describes the hardware specifications for the Philips UCB1200 driver. This is an SPF driver and works with the UCB1100, UCB1200, and UCB1300.

### Capabilities

The UCB1200 is capable of controlling a microphone/speaker, input/output telecommunications lines, resistive style touch screen, and 16 General Purpose Input/Output lines. This driver currently can only control the touch screen, and general purpose input/output lines. The microphone/speaker can be controlled with a MAUI Sound driver called `sd_ucb1200`. No driver has been written for the telecommunications part of the UCB1200.

### Descriptors

[Table B-11](#) lists the UCB1200 descriptors.

**Table B-11. UCB1200 Descriptors**

| Name                     | Function                    |
|--------------------------|-----------------------------|
| <code>ucb</code>         | UCB1200 Chip Initialization |
| <code>ucb_audio</code>   | Not Implemented             |
| <code>ucb_touch</code>   | Touch Screen                |
| <code>ucb_gpio</code>    | Control GPIO Lines          |
| <code>ucb_telecom</code> | Not Implemented             |

## UCB

Opening the /ucb device will perform basic chip initialization. Normally this is not necessary, unless another driver is written to control part of the UCB1200 functions. This is the case for audio. The MAUI Sound driver `sd_ucb1200` will open /ucb to perform chip initialization. In this way, the MAUI Sound driver play audio and this driver can control the touch screen at the same time.

## Audio

This portion of the driver is not implemented since the MAUI Sound driver `sd_ucb1200` already exists. `sd_ucb1200` and this driver can co-exist.

## Touch Screen

This portion of the driver controls the touch screen operation. When pressure is applied to the touch screen, a hardware interrupt is raised, and this driver's interrupt service routine will execute. A system state alarm, then, will fire at regular intervals to sample data from the touch screen. When pressure is removed, the alarm stops. This mechanism leaves the UCB1200 in a low power state until the user presses the touch screen. The alarm rate can be controlled in the `ucb_touch` descriptor.

Each sample contains an x, y coordinate as well as pressure information. The data is formatted into a six byte packet as defined in the table below. Each packet contains 10 bits of x, 10 bits of y, and 8 bits of pressure information.

**Table B-12. Touch Screen Descriptor Data**

| Byte number | Description                                                                                   |
|-------------|-----------------------------------------------------------------------------------------------|
| 0           | sync code - 0x80                                                                              |
| 1           | header:<br>bit 1: pendown<br>bit 2: penup<br>bit 3: penmove (may occur with pendown or penup) |
| 2           | bits 0..2: high 3 bits of x<br>bits 3..6: high 4 bits of pressure<br>bit 7: 0                 |
| 3           | bits 0..6: low 7 bits of x<br>bit 7: 0                                                        |
| 4           | bits 0..2: high 3 bits of y<br>bits 3..6: low 4 bits of pressure                              |
| 5           | bits 0..6: low bits of y<br>bit 7: 0                                                          |

## GPIO

This section of the driver has basic GPIO line control, where lines 0..9 are connected to a 7 segment display or LED. Each line can be controlled with an `_os_write()` call. (Refer to the UCBHEX program in the TEST directory.)

## Telecom

This portion of the driver is not implemented.

## Supporting Modules

Before this driver can be used, `spf`, `sysmbuf`, and `mbinstall` must be in memory and `mbinstall` must be run.

## MP\_UCB1200 MAUI Touch screen Protocol Module

This document describes the function of the `mp_ucb1200` protocol module, as well as a high level discussion of the touch screen driver and calibration application.

### Overview

The protocol module converts the driver raw data into a `MAUI_MSG` structure. In this way, applications can remain somewhat ignorant of the details of the hardware since it deals with the MAUI Input layer. In this protocol module, the raw hardware data is converted into screen coordinates. In addition, some data filtering occurs to reduce the amount of erroneous data that the touch screen hardware can produce.

### Data Format

The touch screen driver sends a 6 byte packet that contains x, y, and pressure information. The exact format of this packet is described in the `spuch1200` driver.

### Data Filter

This protocol module filters the data coming from the hardware in an attempt to reduce erroneous data. Two methods are implemented: data point averaging and low pressure point removal. The first method will average the last two points received from the driver. The data point will lag slightly behind the current position, then, but the average will reduce erroneous data points produced by the hardware. The second method throw out data points where the pressure below a certain threshold. It seems that extremely light touches will cause the data to become erratic, although the exact pressure threshold is hardware dependent.

### Raw Mode

An application can put this protocol module in a "raw" mode where data points are not filtered, averaged, or converted to screen coordinates. That is, the data from the hardware is passed directly up to the application.

The application can put this protocol module in a "raw" mode by calling: `inp_set_sim_meth(inpdev, RAW_MODE)`. After calibration, the program will need to put the protocol module back in NATIVE mode by calling: `inp_set_sim_meth(inpdev, DEFAULT_SIM_METH)`. There is a sample touch screen Calibration Application in the `TOUCH_CAL` directory.

When the protocol module is taken out of "raw" mode, it will try to read new calibration data points from the `ucb1200.dat` data module. After the data is read from the module, it is no longer needed.

## `cdb.touch`

The touch screen can be registered with MAUI by loading the `cdb.touch` module in memory before any programs using input are started. This will specify the `spucb1200` as the driver, `cdb.touch` as the descriptor, and `mp_ucb1200` as the protocol module.

## Compile Time Options

Table B-13 shows compile time options used to control the default calibration settings and also the screen size. These options can be specified with a value in the `mp_ucb1200` makefile to modify the defaults.

**Table B-13. Compile Time Options**

| Name                                    | Purpose                                                                                                                                                                                                    |
|-----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>SCREEN_WIDTH</code>               | Screen Width in Pixels                                                                                                                                                                                     |
| <code>SCREEN_HEIGHT</code>              | Screen Weight in Pixels                                                                                                                                                                                    |
| <code>DEFAULT_CALIBRATION_X</code>      | Left Calibration Hardware Point                                                                                                                                                                            |
| <code>DEFAULT_CALIBRATION_Y</code>      | Top Calibration Hardware Point                                                                                                                                                                             |
| <code>DEFAULT_CALIBRATION_WIDTH</code>  | Width of Screen In Hardware Points                                                                                                                                                                         |
| <code>DEFAULT_CALIBRATION_HEIGHT</code> | Height of Screen In Hardware Points                                                                                                                                                                        |
| <code>JITTER_THRESHOLD</code>           | Minimum Pixel Change Required Before Points are Reported to the Application.                                                                                                                               |
| <code>NUM_PTS</code>                    | This allows you to choose how many successive data points to average in order to produce less erroneous screen coordinate data to the application. The default is 2, and valid choices are 1, 2, 4, 8, 16. |
| <code>MIN_PRESSURE</code>               | Any pressure point less than this value will be ignored. This is another way to reduce erroneous data. This represents the 8 bit pressure value we get from the driver. The default is 40.                 |

## Calibration Application

There is a sample calibration application located in the `$(MWOS)/SRC/MAUI/MP/MP_UCB1200/TOUCH_CAL` directory. This application, called `touch_cal`, will present a text message on the screen as well as points for the user to press. After the points are pressed, the protocol module `mp_ucb1200` will be updated with the new calibration information.

### Assumptions/Dependencies

1. A Window Manager must be running before this application will operate.
2. A font module must be present to run the demo. `default.fnt` is the default module, or you can specify one on the command line.
3. `touch_cal` will open the first `CDB_TYPE_REMOTE` device in the `cdb`.

### Command Line Options

- `-f [=] <outfile>` Specifies the filename of the calibration information module. This program will write the calibration information to this filename if it is specified. The file contains the calibration information as a data module, thus allowing the information to be stored on disk, nv RAM, flash, etc., for use the next time the hardware is rebooted.
- `-c` This option only works if `-f` is specified. This will cause the calibration program to run only if the filename specified with `-f` is not present.
- `-m=<font module>` Specifies the font module to use for displaying the text message on the screen.

### Coordination with Protocol Module

The protocol module `mp_ucb1200` and the touch screen application `touch_cal` work together to provide the calibration functionality. `touch_cal` must first open the touch screen device, and then must set it into Raw Mode. After the user selects each calibration point, `touch_cal` computes the average of them. These averaged hardware points (as well as the screen resolution) are then stored in a data module called `ucb1200.dat`. When the input device is taken out of Raw Mode, the protocol module will link to `ucb1200.dat` and update itself with the new calibration information.

### Compiling

The makefile for `touch_cal` exists in the `$(PORTS)/MAUI/MP_UCB1200/TOUCH_CAL` directory.